


Installation Requirements



- Width:** 48 inches (120cm) is recommended width if Filler and Orienter are operated on same table. 34 inches (90 cm) is minimum width to operate Filler if Orienter is kept on another table.
- Depth:** 30 inches (75cm) depth is recommended. 24 inches (65cm) is the minimum depth.
- Height:** 29 inches (73cm) or office desk height is recommended.

Electricity is required for optional Vibrator. No compressed air or water is required for operation.

Filler	Hand Held Orienter	European Style Orienter



For detailed measurements and information on selecting a powder hood, visit <http://www.profiller.com/powder-hood>.

Shipping Information

	Item	Boxes	Shipping Wt		Net Wt	
			Kg	Lbs	Kg	Lbs
<p>ProFiller 3700</p>	Bench Top Filler & Hand Held Orienter for one capsule size	Box 1	12.5	28.0	6.0	13.0
		Box 2	47.0	103.0	26.0	57.0
	Extra Change Parts		25.0	5.7	6.5	14
	Optional Vibrator		14.5	32.0	10.5	23.0

	Item	Boxes	Shipping Wt		Net Wt	
			Kg	Lbs	Kg	Lbs
<p>ProFiller 3800</p>	Bench Top Filler & European Style Orienter for one capsule size	Box 1	13.0	29.0	6.5	14.0
		Box 2	47.0	103.0	26.0	57.0
		Box 3	52.5	116.0	25.2	55.0
	Extra Change Parts		11.5	25.0	5.5	12.0
Optional Vibrator		14.5	32.0	10.5	23.0	

<p>Inox (SS316) Filler</p>	<p>For Inox (SS316) Filler add 12 kg (27 lbs) to shipping and 11kg (24lbs) to the net weight of Box 2. For Inox (SS316) Vibrator add 2.5 kg (6 lbs) to shipping and net weight of box for vibrator.</p>
-----------------------------------	---

